
## **CAN DI Self test**

Please confirm the connection among OBD interface, candi main cable, GM and power is correct. When test candi, you must provide power from OBD connector, please refer to the following picture.









Version 1.00					
FO: POST	Rogults				
F1: Self	Test	,			

CANdi POST Resu Test Complete	Test stat
CANdi Present	Pa
Boot S/U Revision	1.
App. S/W Revision	4.
Harduare Revision	
CANdi RAM	Pa
CANdi Boot	Pa
UART Data Link	Pa

CANdi Diagnost	ics
Version 1.0	
F0: POST Results	
F1: Self Test	
9.	
CANdi Self Test	Results
Test Complete	Test status
CANdi Present	Pass
Boot S/U Revision	1.60
App. S/W Revision	4.50
Hardware Revision	1.00
CONTRA DOM	Pass
CANdi RAM	Pass
CANdi Boot	
CANdi Resident CANdi Application	
CHNEI HEDIIGUIUN	

CANdi Application Low Speed Data Link Hed. Spd. Data Link

10.

Mark: there are two kinds of CANDI self test, please

refer to the picture NO.8 and NO.10.